



HP Envy M6-1205DX Battery Replacement

We will be showing the user how to replace the computer's battery.

Written By: Alex Wasilewski



INTRODUCTION

We are showing the simplest replacement you can do to this computer. Replacing the battery is an easy solution if your battery life is getting shorter and shorter.

Step 1 — Battery



- Lay the device face down to begin.

Step 2



- Slide the release mechanism to the left to release the battery.

Step 3



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-14 01:22:36 PM.